



# LogiLink®

## Hand Warmer Power Bank 4000 mAh

Art. No.: PA0264




**Smart  
Fast Charging**

**4000**  
mAh

**Fast**  
Heating

**10W**  
Input/Output

**Portable**  
Design



## Warm Hands, Warm Hearts

Warm your hands while travelling, skiing or hiking in the winter with this LogiLink Hand Warmer Power Bank. Heats up within seconds and at just the right temperature. It also can be used as a portable power bank; the 4000 mAh battery capacity can give a full fast charge to most mobile smartphones.



RoHS  
compliant



\*The specifications and pictures are subject to change without prior notice.  
\*All trade names referenced are the registered trademarks of their respective owners.



PA0264




4 052792 063547

Made in China



### Keep Your Hands Warm

Double-sided heating with three adjustable temperature settings; fast heating in less than 5 seconds. Great for keeping you warm at all times during the cold winter.



⚡ 2A  
Micro-B  
Input

### Power on the Go

The 4000 mAh capacity provides 2 A fast charging for your mobile devices wherever you are.



4000mAh ⚡⚡



⚡ 2A  
USB-A  
Output



RoHS  
compliant



\*The specifications and pictures are subject to change without prior notice.  
\*All trade names referenced are the registered trademarks of their respective owners.





### Pocket-Sized Portability

Lightweight and smooth design, easily hold in hand and slips into your pocket or bag. Take it with you wherever you go.

### Multiple Protection

Extremely safe and reliable; comes with overcurrent, overvoltage, overheating and short circuit protection.

### Wide Compatibility

Compatible with any USB-enabled device such as smartphones, smartwatches, headphones, digital cameras and much more.

### How to Use:

#### » Heating Mode

- a. Press and hold the power button for 5 seconds to enter the heating mode and the LED light will be red.
- b. At the beginning of the heating mode is the highest heat level, press the power button to change the mode.  
(Turn OFF: Press Power Button 2 times in a row until indicator lights turn off)

#### » Charging Mode

- a. Press the power button to enter charging mode, the light will be blue.
- b. Connect your devices to output USB port of power bank via USB charging cable of your device.
- c. When PA0264 is charging to your devices, the blue LED displays the battery status.



RoHS  
compliant



\*The specifications and pictures are subject to change without prior notice.  
\*All trade names referenced are the registered trademarks of their respective owners.



# LogiLink®

## Hand Warmer Power Bank 4000 mAh

Art. No.: PA0264

### Specification:

Battery Capacity	4000 mAh
Battery Type	3.7 V Li-ion
Input Power (max.)	5 V/2 A (10W)
Power Input Interface	Micro-B
Output Power (max.)	5 V/2 A (10 W)
Power Output Interface	USB-A
Housing Material	Aluminum and plastic
LED Indicator	Indicator for charging mode and heating mode
Heating Modes	Low: 30 °C (7 hrs), Medium: 37 °C (3-4 hrs), High: 50 °C (2.5 hrs)
Intelligent Fast Charging	Yes
Working Temperature	0-45°C
Color	Metal Grey
Cable Length (cm)	30 cm
Dimensions	10.5x5.8x2.6 cm
Weight	140 g

### Package Contents:

- » 1x Power Bank
- » 1x USB Charging Cable
- » 1x Carrying Bag
- » 1x User Manual

### Package Information:

- » Packing Dimension: mm
- » Packing Weight: kg
- » Carton Dimension: mm
- » Carton Q'ty: pcs
- » Carton Weight: kg

- ⚠ Please Keep away from water
- ⚠ Do not charging and heating simultaneously
- ⚠ Please stored in a cool dry place when not in use

\*The specifications and pictures are subject to change without prior notice.  
\*All trade names referenced are the registered trademarks of their respective owners.

